



NHTSA SAFETY RECALL

DEALER INSTRUCTIONS

Flat Matte (“Primer”) Finished Motorcycles Recall #05E-082

Identification:

All Big Dog Motorcycles motorcycles painted in Flat Matte (“primer”) finish. Install Warning Label, seat retention material on Flat Matte (“primer”) finish motorcycles, two-up seat and rear footpegs.

WARNING: Due to inadequate suction to the rear fender, pillion pads or two-up seats without retention material installed that attach with suction cups can **not** be used on these motorcycles because of their primer paint job. Installing a pillion pad on this particular paint finish could result in the pillion pad sliding off the rear fender and possibly injuring the passenger.

IMPORTANT: Dealer MUST install label when motorcycle is available either due to recall or service.

1. Remove solo seat and pillion pad (or two-up seat if applicable). To remove; locate suction release tabs under rear of seat with your fingertips. Relieve suction by prying release tabs upwards with fingertips. Remove seat, being careful not to scratch any painted surface.
2. Remove protective backing from warning label and apply to rear fender area shown (See fig. A). Warning label should be located approximately one (1) inch above top of harness grommet (except K-9, which should be mounted two (2) inches above fender edge) and centered at an equal distance from the fender sides.
3. Cut the 1-1/2” wide hook section, P/N 240-000152-00 to length (5” long for K-9, Bulldog, Chopper and Mastiff, 6” long for Pitbull and Ridgeback).



A. TYPICAL.

1. Approximately one (1) inch above harness grommet.
2. Label centered on fender.



B. TYPICAL.

1. Approximate retention material (hook tape) installation area.

4. Remove the adhesive backing, center and apply the retention material to the fender (See fig.**B**). On K-9, Chopper and Mastiff models, the material should be placed 4" to 5-1/2" from front edge of fender. On Pitbull and Ridgeback models, the material should be placed from 3-1/4" to 4-3/4" from the wiring grommet.
5. Install two-up seat with retention material.
6. Install passenger footpegs as required.
7. Return the original solo seat after performing the two-up seat exchange.

Enter a Warranty Claim for this procedure through AWS using Labor Op **R05E-082**.

If further assistance is necessary, contact Big Dog Motorcycles Technical Support at 316-219-7000.