

REQUIRES PARTS TO BE ORDERED FROM Starcraft for every unit.

ACTION REQUIRED:

Add bracket to spare tire carrier

MODELS / UNITS:**Comet Camping Trailer**3611HW **E2BT** 5050-5052, 5055-5059, 5061-5063, 5068, 5071-5072, 5074-5075, 5080**KIT CONTENTS**

Note: Kit can only be ordered using the order form included with this bulletin.

Bracket w/2 screws
Instruction sheet**TOOLS/MATERIAL REQ.:**Screw gun with a 3/8" socket
Putty knife or similar tool**INSTRUCTIONS**

1. Remove the (2) screws from the spare tire carrier. Set aside for re-use. Remove the paper backer from the putty tape on the back of the bracket. **NOTE: The spare tire must be removed from the carrier prior to installing the bracket.**



2. Line up the center holes in the bracket with the existing holes in the tire carrier. Install the (2) original screws in the center holes (**Fig 2a**). Install the (2) additional screws (included with the kit) in the outside bracket holes (**Fig 2b**).

NOTE: Do not over tighten the bolts. Over tightening may strip out the screw holes resulting in the bracket not being securely fastened.



3. Using a putty stick or similar tool, remove the excess putty from the edge of the bracket. **Note: Do not use a knife or sharp tool to remove the putty as it may damage the surface of the unit.**

