

September 25, 2012

Repair instructions for Surveyor Travel Trailer L.P. Gas Line.

Turn off L.P. Gas bottles; disconnect regulator pig tail from the bulkhead fitting. Chock tires on the trailer before starting the investigation and repairs.

1. Inspect the L.P. Gas line around the axle area for any indication of damage to the line.
2. If there is no damage, remove the support loops along the main rail on the frame to remove the support for the L.P. Gas line. See picture #1.
3. Carefully reroute the gas line to the side of the main rail on the frame towards the middle of the unit. See picture #2
4. Install offset support loops so that the main L.P. Gas line remains between the main rails. See picture #2.
5. Connect manifold pressure gauge to L.P. system and check for leaks.
6. If the L.P. Gas line is damaged, remove the line from between the cross tee's or the bulkhead fitting and the cross tee. Depending on the floor plan.
7. Then do steps 2 through 5.

If there are any questions please contact the Surveyor Warranty Department 574-642-3119